



AT-RLM-044

HOOK-UP THE SAME AS AT-RLM-024 & AT-CSR-011



NOTE: THE OPERATION IS DIFFERENT!

THE MANUAL OVERRIDE SWITCH MUST BE PUSHED AND HELD WHILE OPERATING THE SLIDE ROOMS, ONCE IT IS RELEASED, THE MODULE WILL LOSE POWER AND NOT WORK!



GENERIC SWITCH PANEL/COULD BE SINGLE SLIDE

WIRE PIN-OUT, COLOR & FUNCTION

